



## DIN W72×H72, W48×H96, W144×H72mm Counter/Timer

### Features

- 36 input modes and 20 output modes
- Counting speed: 1cps/30cps/2kcps/5kcps
- Selectable voltage input (PNP) or No voltage input (NPN)
- Addition of Up/Down input mode
- Wide range of power supply: 100-240VAC 50/60Hz 12-24VAC 50/60Hz, 12-24VDC universal
- Selectable Counter/Timer by internal DIP switch
- Various time range
- Built-in Microprocessor





### Ordering Information

<b>X</b> 4	П Н — [2	2P		
			I	Indicator
		Output	No mark	Single preset
			2P	Dual preset
	Size		L	DIN W144×H72mm
	Size		Н	DIN W48×H96mm
			No mark	DIN W72×H72mm
	Digit		4	9999 (4 digit)
Itam			6	999999 (6 digit)
Item			FX	Counter/Timer

## Specifications

	Single p	reset	FX4	FX6	FX4H	<u> </u>	<u> </u>
Model	Dual pre	set	FX4-2P	FX6-2P	FX4H-2P	FX4L-2P	FX6L-2P
	Totalizer	(Indicator)	FX4-I	FX6-I	FX4H-I	FX4L-I	FX6L-I
Digit			4 digit	6 digit	4 digit	4 digit	6 digit
Digit size			W8×H14mm	W4×H8mm	W6×H10mm	W8×H14mm	
Power	AC power	er	100-240VAC 50/	60Hz		,	
supply	AC/DC p	ower	12-24VAC 50/60	Hz, 12-24VDC			
Allowable	voltage r	ange	90 to 110% of ra	ted voltage			
Power	AC power	er	<ul> <li>Indicator type: I</li> </ul>	Max. 6VA • Single	preset: Max. 7VA • Dual p	reset: Max. 8VA (100-24	OVAC 50/60Hz)
con- sumption	AC/DC power      Indicator type: Max. 5.8VA • Single preset: Max. 6.8VA • Dual preset: Max. 7.6VA (12-24VAC 50/60 • Indicator type: Max. 2.7W • Single preset: Max. 3.3W • Dual preset: Max. 3.8W (12-24VDC)						
Max. coun	ting speed	d for CP1, CP2	Selectable 1cps/	30cps/2kcps/5kcp	s by internal DIP switch		
Min. input	RESET	input	A 00				
signal width	INHIBIT	input	Approx. 20ms				
	CP1, CP2 input		Input logic is selectable				
Input	(INHIBIT)		[Voltage input] Input impedance: 5.4kΩ, "H" level: 5-30VDC, "L" level: 0-2VDC				
	RESET input		[No-voltage input] Impedance at short-circuit: Max. $1k\Omega$ , Residual voltage at short-circuit: Max. $2VDC$ , Impedance at open-circuit: Min. $100k\Omega$				
One-shot output time		<ul> <li>Single preset type - 0.05 to 5sec.</li> <li>Dual preset type - 1st. output 0.5sec. fixed, 2st. output: 0.05 to 5sec.</li> </ul>					
	Contact	Туре	Single preset type: SPDT (1c), Dual preset type: 1st output SPDT (1c), 2nd output SPDT (1c)				
Control	Contact	Capacity	250VAC 3A at re	sistive load			
output	Solid-	Туре	Single preset: 1 NPN open collector Dual preset: 1st output 1 NPN open collector, 2nd output 1 NPN open collector				
	state	Capacity	30VDC Max. 100	30VDC Max. 100mA Max.			
Memory p	rotection		Approx. 10 years (When using non-volatile semiconductor memory)				
External s	ensor po	wer	12VDC±10% 50mA Max.				
Environ-	ron- Ambient temperature		-10 to 55°C, storage: -25 to 65°C				
ment	ment Ambient humidity		35 to 85%RH, storage: 35 to 85%RH				
Insulation resistance		Min. 100MΩ (at 500VDC megger)					
Dielectric strength		2000VAC 50/60Hz for 1 minute					
Noise	AC po		±2kV the square wave noise (pulse width: 1μs) by the noise simulator				
strength	DC po	wer	±500V the square wave noise (pulse width: 1µs) by the noise simulator				


J-50 **Autonics** 

### Specifications

		,						
Vibration	Mechanical	0.75mm amplitude at frequency of 10 to 55Hz (for 1 min.) in each X, Y, Z direction for 1 hour						
VIDIALIOII	Malfunction	0.5mm amplitude at frequency of 10 to 55Hz (for 1 min.) in each X, Y, Z direction for 10 min.						
011	Mechanical	300m/s² (approx. 30G) in each X, Y, Z direction for 3 times						
Shock	Malfunction	100m/s² (approx. 10G) in each X, Y, Z direction for 3 times						
Relay Mechanical Min. 10,000,000 operations								
life cycle	Electrical	Min. 100,000 operations at 250VAC 2A (resistive load)						
Approval		c ¶ us (Except for AC/DC power type)						
Weight <sup>⊗1</sup>		FX4: Approx. 385g (approx. 249g) FX4-2P: Approx. 396g (approx. 258g) FX4-I: Approx. 353g (approx. 216g)	FX6: Approx. 395g (approx. 259) FX6-2P: Approx. 398g (approx. 262g) FX6-1: Approx. 351g (approx. 214g)	FX4H: Approx. 349g (approx. 234g) FX4H-2P: Approx. 375g (approx. 261g) FX4H-I: Approx. 321g (approx. 206g)	FX4L-2P: Approx. 651g (approx. 467g) FX4L-I: Approx. 593g (approx. 400g)	FX6L-2P: Approx. 678g (approx. 494g) FX6L-I: Approx. 586g (approx. 404g)		

X1: The weight includes packaging. The weight in parentheses is for unit only.

XEnvironment resistance is rated at no freezing or condensation.




- $\times$  CP2 (INHIBIT): Time hold terminal when using for timer.  $\times$  It is operated by power ON start type when using for timer.
- X 1. Connection for PNP input2. Connection for NPN input

## **FX/FXH/FXL Series**


### Dimensions

### • FX Series





Panel cut-out




(unit: mm)

(unit: mm)


(unit: mm)

• FXH Series







Panel cut-out



• FXL Series





Panel cut-out



### **■** Input Connections

- No-voltage input (NPN) (Factory default)
- Solid-state input (Standard sensor: NPN output type sensor)






67

XCP1, CP2 (INHIBIT), RESET input


### Contact input




Counting speed: 1 or 30cps setting (Counter)

### O Voltage input (PNP)


• Solid-state input (Standard sensor: PNP output type sensor)







• Contact input



Counting speed: 1 or 30cps setting (Counter)

### Input Logic Selection

#### FX Series

Input logic is changeable by input logic selection switch located at the one-side of case

No-voltage input (PNP)
 NPN PNP NPN PNP
 PNP NPN PNP

#### • FXL Series

Input logic is changeable by input logic selection switch located at the terminal block.

• No-voltageinpu (NPN)
(NPN) F ■ S

Voltage input (PNP)

F S (PNP)

#### FXH Series

Input logic is changeable by input logic selection switch (SW3) located at inside of the case.

 No-voltage input (NPN)  Voltage input (PNP)



NPN UUU PNP




Direction of front display

XPlease be sure to turn power OFF before changing input logic.


### Input & Output Connections

In case of operating the load by power supply of the sensor




- Please select proper capacity of load, because total value of load capacity and current consumption should not be exceed current capacity. (Max. 50mA)
- How to count by external power supply This unit starts to count when "High" level (5-30VDC) is applied at CP1 or CP2 after selecting PNP.

In case of operating the load by external power supply




- The capacity of the load must not be exceed max. 30VDC, max. 100mA of the switching capacity of the transistor.
- Please do not supply the reverse polarity voltage.
   Please connector the surge absorber (Diode) at both terminals of the load, in case of using the inductive load. (Relay, etc.)



#### Using 2 counters with one sensor


Please connect as the power of sensor is supplied from only one of counters and design input logic with same way.




# **FX/FXH/FXL Series**


### Description Of Inner DIP Switches


### • FX Series





#### FXL Series





1st output one-shot (ON/OFF)

Output mode

Up/Down mode

Count input mode (Counter)


Time setting mode (Timer)

Memory protection (ON/OFF)

Counter/Timer selection

Max. counting speed (Counter)

 X1: Single preset model (There is 8 of SW1)



**%2: Indication model** (There is 5, 6, 7, 8 of SW1)



### Max. counting speed

SW2	Functions
ON OFF	1cps
ON OFF	30cps
ON 2 OFF	2kcps
OFF 2	5kcps

### • Conter/Timer selection

SW	/2	Functions
3	ON OFF	Conter
3	ON OFF	Timer

### • Memory protection

		-
SW	2	Functions
4	ON OFF	Disable the memory protection
-	ON OFF	Enable the memory protection

#### • Up/Down mode selection


SV	/1	Functions
4	ON OFF	Down mode
-	ON OFF	Up mode

#### • 1st output one-shot (ON/OFF)

	, , , , , , , , , , , , , , , , , , , ,			
SV	V1	Functions		
8	ON OFF	1st output: One-shot output		
0	ON OFF	1st output: Retained output		


XThis mode selects a one-shot output (0.5sec. fixed) or retained output (Until 2nd output turns off) for 1st output in the dual preset coaunter.

#### **X**Example of F output operation mode



J-54 **Autonics** 

## **■** Input Operation (Counter)



※ (A): Over min. signal width, (B): Over 1/2 of min. signal width.

If the signal width of (A) or (B) is less than min. signal width, ±1 of count error occurs.

If the signal width of (A) or (B) is less than min. signal width, ±1 of count error occurs.

If the signal width of (A) or (B) is less than min. signal width, ±1 of count error occurs.

If the signal width of (A) or (B) is less than min. signal width, ±1 of count error occurs.

If the signal width of (A) or (B) is less than min. signal width, ±1 of count error occurs.

If the signal width of (A) or (B) is less than min. signal width, ±1 of count error occurs.

If the signal width of (A) or (B) is less than min. signal width, ±1 of count error occurs.

If the signal width of (A) or (B) is less than min. signal width, ±1 of count error occurs.

If the signal width of (A) or (B) is less than min. signal width, ±1 of count error occurs.

If the signal width of (A) or (B) is less than min.

If the signal width of (A) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.

If the signal width of (B) or (B) is less than min.


If the signal width of (B) or (B) is less than min.

If the signal width of (


### **■** Time Setting Mode (Timer)

		, , , , , , , , , , , , , , , , , , ,	I
SW1		4digit	6digit
A	1 2 3 ON OFF	99.99sec	99999.9sec
В	ON OFF	999.9sec	999999sec
С	1 2 3 ON OFF	9999sec	99min 59.99sec
D	ON OFF	99min 59sec	999min 59.9sec
E	ON OFF	999.9min	9999.9min
F	ON OFF	99hour 59min	99hour 59min 59sec
G	ON OFF	999.9hour	9999hour 59min
н	1 2 3 ON OFF	9999hour	99999.9hour


### Counting Operation Of Indication Type (Counter)




### • Up / Down-A, B, C mode




#### • Down mode



#### Up / Down-D, E, F mode




## Type (Timer)




■ Time Operation Of Indication

## Down mode RESET



### Setting Function Of Decimal Point



- XIt advances to "Decimal point setting mode" if press RESET key for 3sec.
- XIt returns to RUN mode by press RESET key for 3sec in "Decimal point setting mode".
- XIt returns to RUN mode if no RESET button or digital switch (Dual-setting digital switch for dual preset type) is applied for 60sec. in the "Decimal point setting mode".
- \*The decimal point setting does not exist in indicator.

#### Decimal point setting

· The decimal point setting of 6digits indicator


- <u>+</u> ..... + ..... + .... + .... + .... + .... + .... + .... + .... + .... + ..... + .... + .... + .... + .... + .... + .... + .... + .... + ..... + .... + .... + .... + .... + .... + .... + .... + .... + ..... + .... + .... + .... + .... + .... + .... + .... + .... + ..... + .... + .... + .... + .... + .... + .... + .... + .... + ..... + ..... + .... + .... + .... + .... + .... + .... + .... + .... + ..... + .... + .... + .... + .... + .... + .... + .... + .... + ..... + .... + .... + .... + .... + .... + .... + .... + .... + ..... + .
- The decimal point setting of 4digits indicator



- XExisting decimal point setting is displayed when entering into decimal point setting mode.
- - If pressing one of digital switch (2nd preset type: 2nd preset digital switch) Down (-) buttons, decimal point will be moved to Down (-) direction.

J-56

## **Up/Down Counter/Timer**



XOne-shot output time is set by front TIME adjuster.

## FX/FXH/FXL Series



### Proper Usage


### O Reset

#### Reset

In case of changing the input mode after supplying the power, please provide an external reset or manual reset. If reset is not executed, the counter will be working in previous mode.


#### • Reset signal width

To guarantee proper reset, the signal must be supplied for a minimum of min. 20ms regardless the signal comes from a contact or a solid-state input.



- X1: In case of a contact reset, contact chattering will not affect the reset as long as it is applied for a minimum of 20ms.
- ※2: Input signal at CP1 & CP2 must be applied for a minimum of 50ms after the reset is removed.

### O Mini. count signal width




%1: Please make duty ratio (ON/OFF) as 1:1.

\*2: Min. signal width 1cps: Min. 500ms 30cps: Min. 16.7ms 2kcps: Min. 0.25ms 5kcps: Min. 0.1ms

#### Max. counting speed

This is a response speed per 1 sec. when the duty ratio (ON:OFF) of input signal is 1:1. If the duty ratio is not 1:1, the width between ON and OFF should be over min. signal width and the response speed will getting slower against input signal. If either ON or OFF signal is shorter than minimum signal width, this product may not respond.




Ta (ON width) and Tb (OFF width) needed to be over min.signal width.

Max. counting speed is 1/2 value of rated spec. when duty ratio is 1:3.

It can not respond if it is smaller than min. singal width (Ta).

#### O Power


The inner circuit voltage starts to rise up for the first 100ms after power on, the input may not work at this time. And also the inner circuit voltage drops down for the last 500ms after power off, the input may not work at this time.




# (c):051-37133855-6

WWW.ARCOKALA.COM

### O INHIBIT (For timer)



- INHIBIT mode is active when SW1 turns ON. (Time Hold)
- When power is applied, it starts to progress and INHIBIT mode is used to stop the time is under the progress at the moment.
- When SW1 is OFF, timer starts to progress again.



#### O How to use the sticker

The below sticker can be found inside the box. Use the sticker according to application as follow;

E.g. 1) Measurement of length E.g. 2) The by the rotary encoder

E.g. 2) Timer[F mode]





Please put black dot.

Please put black dot.

#### © Error display

Error signal	Error description	Returning method
		Change the setting value to non zero status
ErrO	When 2nd setting value is smaller than 1st setting value	Make 2nd setting value bigger than 1st setting value

XThere is no Error display function in indication type.

\*There is no Error function in indicator.

\*When Error is display, the OUTPUT continues OFF state.

 $\times$ 1st output maintains OFF status by 1st setting value as 0.





#### O Case & DIP switch detachment


#### FXH Series

FXL Series

1 Push down the front guide.

2 Pull out the front guide.





\*Please be careful of the injury caused by tools.